



PALLET FORKS FOR 3-POINT

ITEM : AC20003PT



USER MANUAL

TABLE OF CONTENTS

Product informations	1
Introduction	2
Installation	3
Configurations	4
Safety	5
Spare parts	6
Notes	7

Product informations

Retailer	_____
Seller	_____
Phone	_____
Serial number	811 _____
Purchase date	_____

INTRODUCTION

Congratulations on the purchase of your Rear Lift Pallet Fork Set. You will be delighted by the versatility offered by this quality product.

On the next few pages, we will present the information and instructions concerning your model. You will find instructions for assembly, use and spare parts. Do not forget to follow all the safety instructions in order to use your product in a safe way for you and others.


Take advantage of all the benefits your product has to offer and if you need more information, help or advice, we are here for you! Contact us easily as follows:

- E-Mail : info@agri-can.com
- Phone : 1-888-997-2624
- Live chat via our website
- Messenger and Instagram

On behalf of everyone at Agri-Can, thank you for your confidence. We are convinced that this guide will be of use to you, but that your purchase will be even more so!

Enjoy it!

INSTALLATION



Like all 3-point type accessories, installation is very simple. The attachment is made up of 3 eyelets. Make sure that the components of the tractor and the set of forks is clean and free of mud, stones, branches and the like. This will affect the proper functioning of the equipment and can be dangerous.

STEP-BY-STEP

1. Position the rear hitch of your tractor as close as possible to the coupling harness of the fork assembly;
2. Lower the hydraulic lift arms to the same height as the hitch;
3. Manually insert the lift arms between the fork assembly clips.
4. Insert the pins making sure to insert it all the way and install the R pin to lock it in place. If the pin is difficult to insert, slightly raise or lower the hydraulic lift arms to help.
5. Lift the adjustment bar (Top Link) in order to position it on the clamp of the fork assembly. If necessary, if the pin does not go in, adjust the length of the adjustment arm so that the pin can go in. It is also important to block this pin with the small R pin.
6. **IMPORTANT :** Once the 3 main pins are in place and secure, raise the fork assembly to just above the ground so that nothing touches the ground. Ensure you are on flat ground, adjust the adjustment bar (top link) of the 3-point so that the forks are parallel to the ground or very slightly inclined towards the tractor.

CONFIGURATION

The main harness includes space for the 2 forks, and you can remove these from the harness by sliding them into the center of the rail and swinging the fork backwards.



It is important to understand the operation and limitations of the various components of the assembly. Your safety is a priority! Take the time to properly attach the various parts before use. No tools are required for configuration changes.

Transport pallets

The forks are held in place using a locking system. Raise the locks and you can move the forks on the rail.

Tips :

- Put a dry lubricant like graphite on the top rail so that the forks slide without restriction and reduce friction.
- If the forks are difficult to slide, tilt the forks slightly towards the rear of the tractor in order to raise the bottom of the forks slightly from the lower rail.

SAFETY




Your safety is important. Don't take any risks with heavy equipment. Your life and that of the people around you depend on it. Here are the basic safety rules for this type of equipment:

- Ensure the harness is securely locked in place on the tractor when installing;
- Ensure that the forks are properly attached to the top and bottom rails and that the safety lock on the top is engaged;
- Wear safety boots when operating machinery;
- NEVER step or stand under the pallet fork and hay spears assembly.
- **ALWAYS** maintain a safe distance with the machinery;
- The operator is responsible for the safety of people and property around him. Be alert to your surroundings;
- Never exceed the limits indicated on the label bearing the serial number;
- Enter pallet forks fully under the load and that at least 2/3 of its length is supported;
- Raise the load vertically until it no longer touches the ground, then tilt it backward;
- Ensure that the load does not catch into neighboring loads or any other objects;
- Do not raise or lower the forks before fully stopping the tractor and applying the handbrake;
- Tilt the load backwards;
- Ride with the forks as close to the ground as possible with the harness angled backward (usually 10 to 15 cm (4 to 6 in.) above ground).
- Avoid sudden stops;
- Ensure there is sufficient headroom before entering or leaving a space, and lifting the forks or spears;
- Do not lift the load when the tractor is on an inclined terrain;
- Never transport anyone on the implement, forks, harness;

SPARE PARTS

To order your spare parts on the website, go to www.agri-can.com and enter the corresponding part number.



#	N° Pièce	Qtée	Description
1	ACFP42	2	Forks 42'' (Capacity 2000 lbs)
2	AC2000ST	1	Safety stickers set (2)

Warning

While Agri-Can® strives to ensure the information is accurate, current and complete, we cannot warrant, declare or promise that the information provided is valid, accurate or current. Agri-Can® shall not be liable for any loss or claim which may arise directly or indirectly from the use of this information.

Agri-Can® assumes no liability in connection with the operation of equipment or damages or injuries that may result. The operator is solely responsible for the safety and good operation of the implement and its various configurations.

If you have any questions about these warnings, do not hesitate to contact us at 1-888-997-2624 or by email at info@agri-can.com.

Manuel AC20003PT
Version 0423
Agri-Can®
© All rights reserved 2023